

How to easily connect your new wireless router

1. The outlet in the wall

Connect a standard network cable to the outlet in the wall. The outlet may look like the one on the right, but can vary.


2. Connect the wireless router

Connect the other end of the network cable to the router. Now connect the router to power. The router is now online.

(You may need to register the router through your bolig:net account. Visit start.bolignet.dk and press the button "Registrer computer".)

3. Connect your phone, tablet ect.

Locate the routers Wi-Fi name (SSID) on the list with Wi-Fi networks, and connect with the password you find underneath here.



Wi-Fi connection info

2.4 GHz:

5.0 GHz:

Password:

Use 2.4 GHz when:

- You want a larger Wi-Fi range in eg. a big house
- You have equipment that can't use 5.0 GHz

Use 5.0 GHz when:

- You have many neighbors with Wi-Fi
- You want to stream movies in HD or 4K

Accessing the routers settings

Bear in mind that if you change the setup, we can't guarantee the router will work! Connect a network cable between your computer and router, open your browser, and type <http://192.168.0.1/> in the address bar. Login with the info you see here on the right.

Router login info

Username: **Admin**

Password:



If you experience any router problems, do not reset it with the reset button in the back, but instead call our customer service for assistance on [70 27 70 67](tel:70277067).